
Choose design, legs and upholstery on your Stressless® Urban recliner

Select design


Make your selection from our 3 different options, - Low Back, Adjustable Headrest and High Back to find the perfect fit for you.

Select base

There are three different bases to choose from, all with one thing in common; unique comfort.

Select upholstery in leather or fabric

See the whole range of leather and fabric at stressless.com




Star base


Cross base

Home Office base




Stressless® London

	Star/Cross Low Back				Star/Cross Adjustable Headrest				Star/Cross High Back			
	W	H	D	SH*	W	H	D	SH*	W	H	D	SH*
	80	86	72	46	80	98-108	75	46	80	111	74	46
	54	42	41		54	42	41		54	42	41	
	Home Office				Home Office				Home Office			
	80	97-104	69	48-55	80	109-126	68	48-55	80	121-128	70	48-55





Stressless® Rome

	Star/Cross Low Back				Star/Cross Adjustable Headrest				Star/Cross High Back			
	W	H	D	SH*	W	H	D	SH*	W	H	D	SH*
	82	92	80	49	82	105-115	77	49	82	110	84	49
	56	47	41		56	47	41		56	47	41	
	Home Office				Home Office				Home Office			
	82	105-112	71	54-61	82	117-124	70	54-61	82	123-130	73	54-61



Stressless® Tokyo

	Star/Cross Low Back				Star/Cross Adjustable Headrest				Star/Cross High Back			
	W	H	D	SH*	W	H	D	SH*	W	H	D	SH*
	80	85	77	47	80	99-113	76	47	80	110	81	47
	54	46	46		54	46	46		54	46	46	
	Home Office				Home Office				Home Office			
	80	95-102	69	49-56	80	109-126	68	49-56	80	120-127	70	49-56

 Adjustable headrest / * Seat height /  Footstool

All measurements in cm. Sizes of individual products may vary by up to 3cm due to the handmade nature of the product.