

Choose design, legs and upholstery on your dining chair

Select design and size

Make your selection from our four designs. With or without armrest.



Select upholstery in leather or fabric

The chairs can be delivered in a vast variety of covers and colours.

See the whole range of leather and fabric options at stressless.com

Select legs in wood or metal

There are six legs to choose from.



Backrest options



Stressless® Bay



Stressless® Laurel



Stressless® Vanilla




Stressless® Mint

Leg options


D100

Leg in wood. Available in four colours.



D200

Leg in wood. Available in four colours.




D300

Leg in steel. Available in three colours.




D400

Leg in steel. Available in three colours.




D350

Leg in aluminium. Available in three colours. 360° swivel auto return optional.



Home Office

Leg in aluminium on wheels. Available in two colours. 360° swivel.





Stressless® Laurel

LEGS	Low back (M)			High back (M)			Low back (L)			High back (L)			Low back (L) w/arm.			High back (L) w/arm			Seat height
	W	H	D	W	H	D	W	H	D	W	H	D	W	H	D	W	H	D	
D100	50	92	56	50	105	57	57	92	62	57	105	63	58	92	62	58	105	63	48
D200	44	92	56	44	105	57	50	92	62	50	105	63	58	92	62	58	105	63	48
D300	50	92	57	50	105	57	57	92	62	57	105	63	58	92	62	58	105	63	48
D350	50	92	56	50	105	57	50	92	62	50	105	63	58	92	62	58	105	63	48
D400	47	92	56	47	105	57	54	92	62	54	105	63	58	92	62	58	105	63	48
Home Office							72	87	72	72	100	72	72	87	72	72	100	72	43-55

Stressless® Mint / Stressless® Vanilla

LEGS	Low back (L)			High back (L)			Low back (L) w/arm.			High back (L) w/arm			Seat height
	W	H	D	W	H	D	W	H	D	W	H	D	
D100	57	92	62	57	105	63	58	92	62	58	105	63	48
D200	50	92	62	50	105	63	58	92	62	58	105	63	48
D300	57	92	62	57	105	63	58	92	62	58	105	63	48
D350	50	92	62	50	105	63	58	92	62	58	105	63	48
D400	54	92	62	54	105	63	58	92	62	58	105	63	48
Home Office	72	87	72	72	100	72	72	87	72	72	100	72	43-55

Stressless® Bay

LEGS	Low back (L)			Low back (L) w/arm.			Seat height
	W	H	D	W	H	D	
D100	57	91	59	59	91	59	48
D200	50	91	59	59	91	59	48
D300	57	91	60	59	91	60	48
D350	50	91	59	59	91	59	48
D400	54	91	59	59	91	59	48
Home Office	72	86	72	72	86-98	72	43-55



Stressless® Bordeaux Round Center table

Ø: 125 H: 74

Stressless® Bordeaux Round table


Ø: 125 H: 74

Stressless® Bordeaux table (M and L)

(M) L: 170 H: 74 D: 100 (L) L: 230 H: 74 D: 100

Stressless® base colours


Ekornes uses rotary cut beech veneer in all its moulded furniture components. Lightly steamed beech is used for solid wood components. The hardness of the wood makes beech furniture extremely durable, and the timber we use is a renewable resource. Beech is a natural material and variations in its pattern, colour and texture make each piece of furniture unique. Although beech is used for both solid and moulded components, structural differences may be visible.



Stressless® Sam and Scott




Stressless® Dining (Dining legs in wood and laminate and tables)




Polished and Matte Metal

Signature, Cross, Star base, and Home Office*



Sirius (Sam/Scott)



Dining (D300, D350, D400, and Home Office)



* Matte Black is not available on Home Office.

* Matte Black is not available on Disc base

* Satin Silver is not available on Home Office

Stressless® Leather and Fabric Care kits

Ekornes offers its own leather and fabric (including microfibre) care kits to match the high quality of our furniture.

The Stressless® Leather Care kit (medium/large) contains a leather cleaner and protection cream. Stressless® Leather Care Wipes are also available. For maintenance, and to make the leather more resistant to stains, the protective cream should be applied to all your recliner's leather surfaces when new. We recommend that you clean the leather with Stressless® leather cleaner at least once every six months to keep your leather looking its best, removing stains regularly and ensuring long leather life. Always apply the protective cream after cleaning.

The Stressless® Fabric Care kit contains a fabric cleaner, a stain remover and an Ox cleaner. This kit contains everything you need to clean your furniture in minutes without removing the fabric cover. For resistant stains, use the fabric cleaner together with the stain remover and Ox cleaner.

These are the only cleaning products recommended by Stressless®. Stressless® accepts no responsibility if cleaning products other than those recommended by Ekornes are used and cause damage to the leather.

